Aquabox O&M Manual





Aquabox Isolator® Row

Regular inspection and maintenance are essential to ensure a properly functioning stormwater system. The Aquabox Isolator Row is a technique to inexpensively enhance Total Suspended Solids (TSS) removal with easy access for inspection and maintenance.

The Aquabox Isolator Row

The Aquabox Isolator Row is a row of Aquabox modules wrapped in filter fabric and connected to a closely located manhole for easy access. The fabric lined modules provide for sediment settling and filtration as stormwater rises in the Isolator Row and passes through the filter fabric. The open structure of the modules allow stormwater to flow out the bottom and sides of the modules. Sediments are captured in the Aquabox Isolator Row, protecting the storage volume in the rest of the modules from sediment accumulation.

ADS Plus fabric is used to wrap the Aquabox Isolator Row. The woven geotextile provides a media for stormwater filtration, a durable surface for maintenance, prevents scour of the underlying stone and remains intact during high pressure jetting.

The Aquabox Isolator Row is designed to capture the "first flush" runoff and offers the versatility to be sized on a volume basis or a flow-rate basis. An upstream manhole provides access to the Aquabox Isolator Row and includes a high/low concept such that stormwater flow rates or volumes that exceed the capacity of the Aquabox Isolator Row bypass through a manifold to the other modules. This is achieved with an elevated bypass manifold or a high-flow weir. After stormwater flows through



the Aquabox Isolator Row and into the rest of the Aquabox system it is either exfiltrated into the soils below or passed at a controlled rate through an outlet manifold and outlet control structure.

The Aquabox Isolator Row may be part of a treatment train system. The treatment train design and pretreatment device selection by the design engineer is often driven by regulatory requirements. Whether pretreatment is used or not, ADS recommends using the Aquabox Isolator Row to minimize maintenance requirements and maintenance costs.



Aquabox Isolator Row Standard Cross-Section

Installing the Aquabox Isolator® Row



Step 1: Roll out one piece of ADS Plus geotextile in the approximate area of the Isolator Row. The geotextile will be placed directly on the ADS 601 non-woven.



Step 2: Continue assembling the system until the modules are two rows away from the Isolator Row. Then roll out a second piece of ADS Plus the exact length of the Isolator Row. Place the edge this geotextile against the modules.



Step 3: Install the next row of modules, placing them on tope of the ADS Plus geotextile. This row requires side panels to be installed on the module sides facing the Isolator Row.



Step 4: Fold the upper layer of ADS Plus geotextile back over the top of the previously installed modules



Step 5: Install the modules of the Isolator Row, including top caps and joints.

Note: only single joints should be used between the Isolator Row modules and no joints should be used between the Isolator Row and adjacent modules.



Step 7: As the next row of modules are assembled, install side panels on the module sides facing the Isolator Row.

Note: do not use joints between the Isolator Row modules and this row.



Step 8: For Isolator Rows that end within the bed, install the module outside the end of the row with a side panel facing the Isolator Row. Place a piece of ADS 601 nonwoven geotextile between the Isolator Row and this final module.



Step 6: Once the Isolator Row modules are installed, fold the ADS Plus geotextile back over the top of the Isolator Row. Pull the geotextile down the other side of the row, removing slack. Begin installing the next row of modules to hold the geotextile in place.



Step 9: The Isolator Row is now completely installed. The geotextile wrap traps sediment in the Isolator Row modules for easy maintenance. Proceed with the rest of the system install.

Aquabox Isolator Row Inspection/Maintenance

Inspection

The frequency of inspection and maintenance varies by location. A routine inspection schedule needs to be established for each individual location based upon site specific variables. The type of land use (i.e. industrial, commercial, residential), anticipated pollutant load, percent imperviousness, climate, etc. all play a critical role in determining the actual frequency of inspection and maintenance practices.

At a minimum, ADS recommends annual inspections. Initially, the Isolator Row should be inspected every 6 months for the first year of operation. For subsequent years, the inspection should be adjusted based upon previous observation of sediment deposition.

The Isolator Row should be inspected via the connecting pipe from the upstream structure. Mirrors on poles or cameras may be used to avoid a confined space entry. Inspection ports (optional) may be used for easy access to the system from the surface.

When the average depth of sediment exceeds 3" (75 mm) throughout the Isolator Row, clean-out should be performed.

Maintenance

The Isolator Row was designed to reduce the cost of periodic maintenance. By "isolating" sediments to just one row, costs are dramatically reduced by eliminating the need to clean out all modules of the storage bed. If inspection indicates the potential need for maintenance, access is provided via a manhole(s) located on the end(s) of the row for cleanout. If entry into the manhole is required, please follow local and OSHA rules for a confined space entry.

Maintenance is accomplished with the JetVac process. The JetVac process utilizes a high pressure water nozzle to propel itself down the Isolator Row while scouring and suspending sediments. As the nozzle is retrieved, the captured pollutants are flushed back into the manhole for vacuuming. Most sewer and pipe maintenance companies have vacuum/letVac combination vehicles. Selection of an appropriate JetVac nozzle will improve maintenance efficiency. Rear facing jets with an effective spread of at least 45° are best. The minimum clear span within the Aquabox modules is 6.5" (162.5 mm)--please ensure cleaning equipment does not exceed this width. ADS recommends a maximum nozzle pressure of 1750 psi be utilized during cleaning. JetVac reels can vary in length. For ease of maintenance, ADS recommends Isolator Row lengths up to 150' (46 m) with a structure at one end, or up to 300' (91 m) with a structure at both ends.





adspipe.com 800-821-6710

ADS "Terms and Conditions of Sale" are available on the ADS website, www.adspipe.com The ADS logo and the Green Stripe are registered trademarks of Advanced Drainage Systems, Inc. © 2024 Advanced Drainage Systems, Inc. 11164 9/24 CS