

INSERTA WYE™ INSTALLATION INSTRUCTIONS

1. Core the hole with recommended Inserta Tee hole saw.

Hole placement should be at the spring line or higher on the host pipe. Typical installation is halfway between spring line and crown of pipe (at 45°). Reference hole saw detail STD-2102 for hole saw selection info. Applying soap and water to the hole saw impact point can be beneficial when coring into the mainline pipe.

2. Remove shavings from mainline pipe, creating a clean hole (Deburr edges as needed).

Place rubber sleeve, with rubber sleeve segments (flanges) on both sides of the mainline' s wall thickness. Align gold line perpendicular to mainline.

3. Lubricate inside of rubber sleeve and outside of PVC hub with provided soap solution.

4. Align red line on PVC hub with the gold line on rubber sleeve.

5. Using a wood block and 4lb hammer, place wood block on installation platform, drive the PVC hub through the rubber sleeve and mainline pipe to the red horizontal homing line on PVC hub, ensuring desired Wye alignment.

6. Place and tighten stainless steel band onto rubber sleeve.

The fitting seals with compression from the PVC hub driving through the rubber sleeve. The stainless steel band does not provide a seal. The stainless steel band fastens the PVC hub and sleeve together while the soap solution is still wet; Once the solution is dry, the stainless steel band's purpose has concluded.



Scan QR code for installation video

For shallow H-20 traffic applications (< 2' of cover) or deep burial applications (>= 25' in burial depth), Inserta Wye shall be encased in concrete. Actual dimensions of concrete must be designed (by others) taking into consideration local soil conditions & other applicable design factors, but shall extend no less than 12” in any direction from the fitting.

ADVANCED DRAINAGE SYSTEMS, INC. ("ADS") HAS PREPARED THIS DETAIL BASED ON INFORMATION PROVIDED TO ADS. THIS DRAWING IS INTENDED TO DEPICT THE COMPONENTS AS REQUESTED. ADS HAS NOT PERFORMED ANY ENGINEERING OR DESIGN SERVICES FOR THIS PROJECT, NOR HAS ADS INDEPENDENTLY VERIFIED THE INFORMATION SUPPLIED. THE INSTALLATION DETAILS PROVIDED HEREIN ARE GENERAL RECOMMENDATIONS AND ARE NOT SPECIFIC FOR THIS PROJECT. THE DESIGN ENGINEER SHALL REVIEW THESE DETAILS PRIOR TO CONSTRUCTION. IT IS THE DESIGN ENGINEERS RESPONSIBILITY TO ENSURE THE DETAILS PROVIDED HEREIN MEETS OR EXCEEDS THE APPLICABLE NATIONAL, STATE, OR LOCAL REQUIREMENTS AND TO ENSURE THAT THE DETAILS PROVIDED HEREIN ARE ACCEPTABLE FOR THIS PROJECT.	INSERTA WYE INSTALLATION INSTRUCTIONS		 4640 TRUEMAN BLVD HILLIARD, OH 43026	DRAWN BY:	SMW
				DATE:	04/20/2026
	OK'S BY:	ENG			
	SCALE:	NTS			
	SHEET:	1			
DRAWING NUMBER			STD-2100A		