

24"-36" Saddle Gasket Installation

Preparing 24"-36" (600-900 mm) gasket and pipe for installation:

- Clean dirt and debris from gasket and pipe surface.
- Make sure gasket seal is in proper orientation.
- NOTE: Pre-stretching gasket before installation is NOT recommended.



Scan QR code
to view
install video.



STEP 1: Initiate installation with gasket splice on bottom of pipe. NOTE: Gasket installation is more difficult in colder temperatures.



STEP 2: Slide gasket onto corrugation until it is difficult to stretch (typically ten and two o'clock positions).



STEP 3: Use a pry bar to stretch the gasket into place. Use the exclusive pry hole technology built into the 24"-36" (600-900 mm) gasket. When gasket is in final location an audible "snap" will be heard.



STEP 4: Check final location of gasket to make sure the gasket is properly positioned completely around the pipe.

