30" Split Coupler

Installation Guide

This installation guide is reference for installing the 30" Split Coupler for the 30" (750 mm) HP Pipe.



Before you start please check to make sure all components are on site.

 First determine the location of where the split coupler will need to be installed. Once that is found, the split coupler will need to be centered across the pipe(s).





2. There are two ends to the split coupler, the end with the "lip" will need to overlap on the flat end, to create the seal. For easier install, stand behind the end with the lip and pull the flat end towards you.







3. Pull the lip over the flat end tightly so that the three holes for the zip ties are accessible and are lined up with the holes in the lip of the split coupler.









4. Once the split coupler is aligned, thread the zip tie through the middle hole of the lip and then through the middle hole of the body of the coupler. Pull tight and thread the end of the zip tie through the square notch. Tighten the tie until you have a tight fit. Continue this process until all three zip ties have been installed.











5. After three zip ties have been zipped tight and ends have been trimmed, the split coupler has been installed.





